## **Procoat**

# Timber Cleaner and Brightener

Product Procoat Timber Cleaner and Brightener

PR413

Description Procoat Timber Cleaner and Brightener is a professional strength cleaner for decks and exterior timber,

formulated to rejuvenate and clean grey, weathered timber, and to prepare new timber prior to staining and

oiling

The unique gel structure allows Procoat Timber Cleaner and Brightener to stay active on the timber for

longer, resulting in a more effective clean.

Active Ingredients Oxalic acid

Dilution For new or lightly greyed timber dilute 1 part cleaner with 4 parts water.

For heavily grey or weathered timber dilute 1 part cleaner with 1 part water.

Application Remove all surface dirt with a broom or brush. Wet the surface with water before applying. Apply the cleaner

to the surface using a soft broom or brush. Leave for 5-10 minutes before scrubbing with a stiff bristle brush or broom. Wash off with a hose or pressure washer before the cleaner dries. Rinse off after a maximum of

20 minutes.

Allow timber to dry thoroughly before painting, staining or oiling.

Important Avoid contact with paints, sealants, metal surfaces and vegetation. If contact occurs, rinse well with water.

Do not exceed application time. Oxalic acid may cause timber discoloration if used for prolonged periods.

For exterior use only.

Health and Safety For detailed health and safety information refer to Material Safety Datasheet (MSDS)

#### Usage

- Provide adequate ventilation during use
- Keep out of reach of children

#### Persona

- Avoid contact with skin and eyes
- Wash hands after use

### Protective equipment

- Wear protective eyewear and waterproof gloves
- When spraying, wear dust mask or suitable respirator

#### Storage

- Store away from direct sunlight
- Store in locked up
- Store in original container

Health Effects If poisoning occurs, contact a doctor or Poisons Information Centre (NZ 0800 764 766).

If swallowed: Rinse mouth with water. Do NOT induce vomiting. Give a glass of water.

Eyes: If in eyes, hold eyes open, flush with running water for at least 15 minutes,



Skin: If skin contact occurs, remove contaminated clothing and wash skin thoroughly. Inhaled: Remove from contaminated area.

Spills and Disposal

Do not allow spilt material to enter drains or other watercourses. Absorb spills with sand or other inert material. Do not pour leftover paint down the drain. Unwanted paint should be kept in a sealed container, such as an empty paint can, and disposed of via special waste collection services. Check with your local council regarding the disposal of empty paint containers. Empty paint containers should be left open in a well-ventilated area to dry out. When dry, recycle steel containers via steel can recycling programs. Disposal of empty paint containers via domestic recycling programs may vary between local authorities.

